

CONVERTING FACTORY 03/04 COBRA IAT SENSOR INTO SLOT MAF SENSOR


To convert to a single plug setup, you must have a slot MAF sensor, 6 wire harness adapter(example below), and 6 pin version(C128) of the factory MAF sensor connector.




***You cannot use the factory connector(C197), as it only has the center 4 pin slots available

Step.1, de-pin slots 2,3,4,5 on the factory MAF connector(C197)


- a. Remove the yellow guard by prying it out from the slot with a pick



- b. De-pin wires one at a time by releasing the clip with a small pick



c. As you release the pin clip pull back on the wire from the connector




Step.2, pin the wires into slots 2,3,4,5 on the new 6pin connector(C128), in corresponding locations.

Step.3, de-pin factory IAT sensor connector in the same manner as the MAF connector

Step.4, pin the wires into the outer slots of the 6pin connector as per the C128 diagram.

C128 Wiring Diagram



Example of completed connector

